

OPERATION

POWER = 6V TO 12V DC

NUMBER OF EFFECTS PER CHANNEL: 1

1 CONNECT A SUITABLE LENGTH OF 2 CONDUCTOR WIRE TO THE TERMINAL BLOCK, CONNECT EFFECT TO THIS LENGTH OF WIRE
 CONNECT EFFECT WITH KEY IN SAFE POSITION (ALWAYS REMOVE KEY WHEN LOADING / UNLOADING PYRO)

2 CONNECT POWER THEN ARM UNIT

3 CORRESPONDING CHANNEL CONTINUITY LED'S WILL LIGHT UP

4 ROTATE CHANNEL SELECTOR SWITCH TO DESIRED CHANNEL TO FIRE


5 PRESS AND RELEASE FIRE BUTTON TO DETONATE EFFECT

NOTE: DO NOT HOLD FIRE BUTTON DOWN CONTINUOUSLY IF EFFECT DOES NOT DETONATE

DAMAGE TO CONTROLLER WILL OCCUR


6 CONTINUITY LED FOR THAT CHANNEL WILL TURN OFF
 (LED MAY REMAIN ON IF IGNITER REMAINS SHORTED)

7 REPEAT STEPS 4 AND 5 FOR REMAINING CHANNELS



⊕ = RED

⊖ = BLACK



TITLE: FOUR CH.MINI CONTROLLER	
DRAWING #	
DRAWN BY: ANGELO	
DATE: 16/7/2009	REV. # 2
FILE NAME FOUR CH MINI CONTROLLER OPER	